
SEWER SERVICE CONSTRUCTION & SEPTIC TANK ABANDONMENT LOCKWOOD WATER AND SEWER DISTRICT



SEWER SERVICE CONSTRUCTION NOTES:

- 1. VERIFY LOCATION OF ALL UNDERGROUND UTILITIES PRIOR TO EXCAVATING.
- 2. SEWER CONNECTION PERMIT TO BE OBTAINED FROM LOCKWOOD WATER AND SEWER DISTRICT (LWSD) OFFICE PRIOR TO CONNECTION TO PUBLIC SEWER.
- 3. PLUMBING ON PRIVATE PROPERTY MAY BE INSTALLED BY THE OWNER OF A SINGLE-FAMILY RESIDENCE USED EXCLUSIVELY FOR PERSONAL USE. A LICENSED AND BONDED PLUMBER OR PUBLIC CONTRACTOR REQUIRED OTHERWISE. ALL WORK TO CONFORM TO THE REQUIREMENTS OF THE UNIFORM PLUMBING CODE, LATEST EDITION.
- 4. CONNECTION TO PUBLIC SEWER MUST BE MADE BY LICENSED AND BONDED PLUMBER OR PUBLIC CONTRACTOR.
- 5. ALLOWABLE BUILDING SEWER PIPE INCLUDES SCHEDULE 40 PVC (ASTM D1785), OR SDR 35 PVC (ASTM D3034), 4" MINIMUM PIPE DIAMETER RECOMMENDED. SEWER SERVICE STUBOUTS TO PROPERTY LINE THAT WERE INSTALLED DURING LWSD PROJECTS WERE 6" DIAMETER (TYPICAL).
- 6. PROVIDE UNIFORM BEDDING ALONG ENTIRE LENGTH OF SERVICE TRENCH.
- 7. FOR ANY SEWER SERVICE CONSTRUCTION WITHIN PUBLIC RIGHT OF WAY, WORK MUST CONFORM TO REQUIREMENTS OF YELLOWSTONE COUNTY PUBLIC WORKS DEPARTMENT (256-2735).
- 8. TEN (10) FEET OF SEPARATION IS TO BE MAINTAINED BETWEEN SEWER AND WATER SERVICE LINES.
- 9. CLEANOUT AT PROPERTY LINE SHALL BE 6" PVC AND SHALL BE BROUGHT TO WITHIN 6-INCHES OF GROUND SURFACE. MUST BE CONTAINED IN A PROTECTIVE UTILITY BOX, SIGMA 8"x4" CLEAN-OUT, OR EQUAL. CLEAN-OUT CAP SHALL BE THREADED. CLEAN OUT DETAIL IS AVAILABLE FROM LWSD.
- 10. SPECIAL CARE REQUIRED WHERE SEWER CONNECTION POINT IS CLOSE TO AN IRRIGATION OR DRAINAGE DITCH. RESTORE DITCH DISTURBANCE WITH BENTONITE AND INSTALL BENTONITE OR FLOWABLE FILL TRENCH PLUG FULL DEPTH ALONG SERVICE TRENCH. SEE MONTANA WORKS, SECTION 02222 (BENTONITE) AND SECTION 02225 (FLOWABLE FILL).

SEPTIC TANK ABANDONMENT NOTES:

- 1. NO SEPTIC TANK SHALL BE CONNECTED NOR OTHERWISE DISCHARGED TO ANY PUBLIC SEWER.
- 2. IF EXISTING TANK IS TO BE LEFT IN PLACE, PERFORM THE FOLLOWING PROCEDURE:
 - a) PUMP SEWAGE OUT OF TANK;
 - b) REMOVE TOP COVER OF TANK:
 - c) FILL TANK WITH EARTH, SAND, GRAVEL, CONCRETE, "LEAN MIX CONCRETE", OR OTHER APPROVED MATERIAL (TANK MAY BE FILLED WITH COVER IN PLACE IF "LEAN MIX CONCRETE" OR HIGH SLUMP CONCRETE IS USED).
- 3. ABANDONED TANKS SHALL BE FILLED WITHIN THIRTY (30) DAYS OF CONNECTION OF THE BUILDING TO THE PUBLIC SEWER.
- 4. CONTACT COUNTY SANITARIAN FOR FURTHER INFORMATION REGARDING SEPTIC TANKS & ABANDONMENT REQUIREMENTS (256-2770).